



Straps

a2 — b2 (+T)

b1 — c1
(seulement si VL non monté)

Switch Prolonge la ZA
En bout de panneau

a3 — b3

a5 — b5